



No	Code	Description	No	Code	Description
1	HN10325	Exhaust Cover	62	HN10282	Bumper
2	BB41701	Screw 6x8	63	HN10296	Driver Guide
3	BB40227	Screw 6x35	64	HN10294	Nose Unit
4	HN70095	Cylinder cap Unit	65	BB40444	Screw 8x30
5	HH14040	O-Ring AS568-040	66	FF31261	Parallel Pin 1261
6	HH11120	O-Ring ARP568-009	67	HN10302	Door Opening/Closing plate
7	HN10275	Piston Stop	68	HN10301	Door
8	KK23516	Compression Spring 3516	69	KK23376	Compression spring 3376
9	CN31892	Head Valve Washer	70	CT10191	Switching Bar
10	HH19708	O-Ring 1A 2,6x39,5	71	KK33090	Torsion Spring 3090
11	HH11157	O-Ring AS568-136	72	FF42214	Step Pin 2214
12	HN10274	Head Valve Piston	73	HN10303	door opening/Closing Lever
13	HH11803	O-Ring P36	74	FF41528	Step Pin 1528
14	HN10279	Main Piston Unit	75	KK33197	Torsion Spring 3197
15	HN10278	Cylinder Seal	76	CT10226	Lever Retaining Rubber
16	HN10276	Cylinder A	77	BB40457	Screw 6x38
17	HH12108	O-Ring 1AG60	78	HN10309	Nail Guide
18	HN10271	Frame	79	HN10297	Nose Tip
19	HN10755	Caution Label	80	HN10213	Feed Finger Retainer
20	CN34088	Trigger Lock Lever	81	HN10289	Contact arm Unit
21	HN10310	Grip Cover A	82	HN10292	Attachment A
22	HN10322	Buffer Seat A	83	HN10293	Attachment B
23	EE31105	Plane Washer 1-6	84	KK23256	Compression Spring 3256
24	CC00402	Nut M6	85	HN10287	Arm guide Unit
25	HH12118	O-Ring 1AG35	86	KK24072	Compression Spring 4072
26	HN10313	End Cap	87	HN10304	Door Opening/Closing Finger
27	TT05425	Air Plug H-FPM	88	JJ22408	C-Retaining Ring 24
28	HN10316	End Plug Cap	89	HN10299	Spring Collar
29	CN34309	Coupling Caution Seal	90	CN31755	Feed Piston Stop
30	HN10756	Name Label (USA)	91	KK23517	Compression Spring 3517
31	FF21201	Roll Pin 2,5x10	92	HH11106	O-Ring 1AP16
32	HN10327	Trigger Lock Dial	93	HN10298	Feed Piston
33	KK23507	Compression Spring 3507	94	FF51613	Hollow Pin
34	FF21235	Roll Pin 3x30	95	HN10754	Caution Label
35	HN10311	Grip Cover B	96	HN10307	Magazine Cap
36	HN10323	Buffer Seat B	97	FF41281	Step Pin 1281
38	HH21002	Seal 002 NBR	98	KK33218	Torsion Spring 3218
39	KK33189	Torsion Spring 3189	99	HN10306	Magazine Holder
40	HH11159	O-Ring ARP568-016	100	FF21101	Roll Pin 3x12
41	HN10326	Trigger Valve Cage	101	HN10308	Magazine Hook
42	HH11151	O-ring ARP568-013	102	HN10737	Magazine Lock Lever
43	HN10283	Trigger Valve housing	103	HN10736	Magazine
44	FF30161	Parallel Pin 161	104	FF41599	Step Pin 1599
45	HH11138	O-Ring 1AP20	105	EE39609	Rubber Washer 1,8x6x2
46	HH11119	O-Ring 1AP6	106	BB71504	Screw 6x35
47	HH11802	O-Ring P7	107	HN10330	Attachment C unit
48	CN33627	Pilot Valve	108	HN10211	Dust Cover
49	HH11113	O-Ring 1AP9	109	CN31083	Dust Cover Fitting
50	KK23129	Compression spring 3129	110	CN30707	Collar
51	HN10328	Trigger Valve Stem	111	HN10501	Guide Holder
52	HH11901	O-Ring 1B 1,4x2,5	112	BB40436	Screw 6x14
53	HN10284	Trigger Valve Cap	113	HN10502	Nail Nose Guide
54	HN10286	Contact Lever	114	HH11132	O-Ring 1AP10A
55	HN81029	Trigger Unit	115	HN10752	End Cap Stem
56	FF22402	Roll Pin 3x16	116	HN10753	Nail Nose Guide B
57	EE39602	Rubber Washer 7	117	HN10757	Trigger Lock Seal
58	HN10300	Feed Pawl	118	HN10758	Caution Label B
59	KK33190	Torsion Spring 3190	119	FF21229	Roll Pin 3x20
60	FF41598	Step Pin 1598	201	HN81032	Trigger Valve Kit
61	HN10277	Cylinder B	202	HN81033	O-Ring Kit