

NO	Part Code	Description	NO	Part Code	Description
1	RB70025	PLANET CAGE B UNIT	110	RB10770	FEED GEAR A
2	BB40427	T-BOLT 4 X 8(REPLACES TA15544)	111	RB10774	WIRE GUIDE C
3	KK23847	COMP. SPRING 3847	112	RB10852	RELEASE STOPPER
4	RB10344	KEY PLATE	113	RB70079	SENSOR BOARD C UNIT
6	RB70027	SUN GEAR UNIT	114	RB70087	WARNING LED UNIT
7	RB70029	MAGAZINE HOLDER UNIT	115	RB70341	MAIN SWITCH UNIT
8	AA21102	PAN-HEAD SCREW 3X4	116	AA31721	SCREW 3X6
9	FF51652	PIN 1652	117	AA74410	SCREW 3X6
10	AA31714	SCREW 2X4	118	RB10400	LEAF SPRING
11	CC41104	HEX.NUT 1-3 FOR HD-12/17(FORMER CC41405)	119	RB10536	MAIN SWITCH BASE
16	CC41101	HEX NUT 1-5	120	RB10537	JOINT, DIAL
19	JJ21603	C-RING 20	121	RB10853	TORQUE DIAL
31	RB10725	INTERNAL GEAR B	122	RB81102	MAGAZINE ASSY
32	RB10726	PLANET GEAR B	123	RB10783	PROTECTOR
33	RB10776	GEAR RETAINER	124	RB10785	BUSH A
36	BB40481	BOLT 3X5	125	RB10786	BUSH B
38	FF41822	STEP PIN 1822	126	RB10787	SENSOR COVER
39	JJ10113	E-RING 2.5	127	RB10791	SENSOR COVER PLATE
40	KK33249	TORSION SPRING 3249	128	RB10792	RETAINING RING
41	RB10370	JAW BASE	129	RB70082	SENSOR BOARD F UNIT
42	RB10735	JAW B	130	AA32708	SCREW 2.6X6
43	RB10779	JAW A	131	RB81103	MAGAZINE COVER ASSY
44	RB70056	MOTOR GEAR B UNIT	132	RB11774	MAGAZINE COVER LOCK
45	RB70026	ARM A UNIT	133	RB10806	ADJUST RING
46	RB70036	WIRE GUIDE A2 UNIT	134	BB40405	BOLT 5X25
47	RB70276	WIRE GUIDE UNIT	135	EE32104	WASHER 2-3
48	AA22415	SCREW 3X8	136	EE39172	WASHER 5.1X12X1.2
49	AA71408	SCREW 3 X 3	137	EE39602	WASHER 7
50	EE31801	WASHER 3.2X7	138	FF31289	PIN 1289
51	FF41729	SETP PIN 1729	139	KK33327	TORSION SPRING 3327
52	KK23849	COMP. SPRING 3849	140	RB81104	FRAME L ASSY
53	RB10737	WIRE GUIDE A1	141	RB81105	FRAME R ASSY
54	RB10743	WIRE GUIDE BASE	142	BB40410	BOLT 3X8
55	RB70039	ARM B UNIT	143	BB40811	BOLT 3X25
56	BB40425	BOLT 3X10	144	RB10970	ELECTRODE BLOCK
57	BB40810	BOLT 3X16	145	KK23656	COMPRESSION SPRING 3656
58	CC41103	HEX. NUT 1-4	146	RB10213	WINDOW
59	FF41730	STEP PIN 1730	147	RB81034	MOTOR COVER ASSY
60	JJ10509	E-RING 4CF	148	RB11769	ELECTRODE PLATE
61	RB10746	WIRE GUIDE B	149	RB10795	GRIP COVER L
62	RB10747	ARM C	150	RB10796	GRIP COVER R
63	RB10748	FIXED CUTTER	153	RB10854	TRIGGER
64	RB10749	CUTTER	154	RB10855	TRIGGER LOCK
65	RB10750	CUTTER CONNERCTING ROD	155	RB70367	MAIN BOARD UNIT
66	RB70277	CUTTER LEVER UNIT	157	RB70101	TRIGGER SWITCH
67	RB11767	CUTTER SHAFT	160	RB10423	LABEL, MAIN SWITCH
69	RB10754	CURL GUIDE A	161	RB10798	WARNING LABEL RB650(CE)
70	RB10755	CURL GUIDE B	162	RB10799	TORQUE ADJUSTMENT LABEL
71	RB70041	COVER L UNIT	163	RB11899	NAME LABEL RB665CE
72	RB70042	MAGNET HOLDER L UNIT	164	RB10846	WIRE LOADING LABEL
73	KK23850	COMP. SPRING 3850	165	RB10847	WIRE SETTING LABEL
74	KK33328	TORSION SPRING 3328	166	RB10962	ARM CAUTION LABEL
75	RB70369	TWIST GUIDE COVER L	167	RB70084	HARNESS 11P UNIT
76	RB10759	TWIST GUIDE SHAFT	168	RB70085	HARNESS 7P UNIT
77	RB11667	SENSOR ROD	169	RB70086	HARNESS 3P UNIT
78	RB70044	COVER R UNIT	170	RB70339	FAN UNIT
79	RB70045	MAGNET HOLDER R UNIT	171	RB11884	FILTER A
80	KK33330	TORSION SPRING 3330	173	RB11004	PROTECTOR C
81	RB70370	TWIST GUIDE COVER R	174	EE39830	WASHER 5.1X 9
82	RB10765	SENSOR BASE	175	RB11885	FILER B
83	RB70080	SENSOR BOARD D UNIT	176	RB10718	SLEEVE GUIDE
84	RB70081	SENSOR BOAD E UNIT	177	RB11762	HOOK L
85	KK33329	TORSION SPRING 3329	178	RB11763	HOOK R
86	LL62013	PLAIN BEARING B-F3-1	179	RB11886	FAN PROTECTOR
87	RB11768	ARM B SET SCREW	180	RB11883	FILTER COVER
88	RB10739	ARM A SET SCREW	181	RB10724	SLEEVE COVER
89	RB10740	WIRE GUIDE LEVER	182	RB11003	PROTECTOR B
90	CC49118	HEX NUT 3X7.5	183	RB70354	MOTOR HOUSING L
95	RB70278	FEEDING GEAR BASE ASSY	184	RB11882	MOTOR HOUSING R
96	RB70299	FEEDING GEAR B UNIT	188	FF31559	PIN 1559
97	FF41728	STEP PIN 1728	189	FF51656	PIN 1656
98	RB10775	RELEASE LEVER	191	JJ10510	RETAINING RING 2.3
99	BB40420	BOLT 4 X 16	192	RB70217	MAGNET HOLDER UNIT
100	EE39121	PLAIN WASHER 5	193	RB11666	ARM COVER
101	EE39168	WASHER 4.2X1.3X1	201	RB70349	TWISTING MOTOR TD5046 UNIT
102	FF51628	HOLLOW PIN 1628	202	RB70351	FEEDING MOTOR RS-55VC UNIT
103	JJ10514	E-RING 3 CF	203	RB70222	FEED GEAR SHAFT
104	KK23851	COMP. SPRING 3851	205	RB70113	MAIN SWITCH BASE ASSY
105	LL11181	WHEEL 6704	207	RB70284	TWISTER ASSY
106	RB10043	STEP PIN	208	RB70033	FINGER BASE ASSY
107	RB10338	INTERNAL GEAR	209	RB70281	ARM A ASSY
108	RB10341	PLANET GEAR	210	RB70285	ARM B ASSY
109	RB10484	GEAR PRESS WHEEL	211	RB70283	TWISTER A ASSY